

---

## Appendix F. S3 Trio64V+ Super VGA Driver Installation

Some application programs require custom software, known as device drivers, to take full advantage of the S3 video controller installed in your Industrial Computer. Device drivers are special programs that enable your operating system and application programs to use the advanced capabilities of the video controller. The operating system loads these programs after the hardware is configured. Many applications come with drivers that are compatible with the S3 video controller.

**Note:** Your system unit has an S3 Trio64V+ video controller. Use only the SVGA device drivers supplied with this system unit (or a later version) as earlier versions might not work properly.

Device drivers are supplied on diskettes. You must install the device drivers onto your hard disk. The instructions for installing or copying the device drivers are provided in this appendix. Technical notes and device driver features (if applicable) are included in README files located in the directories containing the drivers.

---

### Default Resolutions

If your system unit comes with *preinstalled* software, your S3 Trio64V+ drivers are already installed. Your system unit video resolution has been set to 640 x 480 x 64K colors. You can change the monitor resolution using procedures in this book.

---

### Operating Systems

If your system unit does not have preinstalled software, the diskettes that come with the 7587 Industrial Computer contain the following device drivers:

- Operating systems
  - OS/2 and OS/2 Warp
  - Microsoft Windows 3.1
  - Microsoft Windows 95
  - Microsoft Windows NT
- DOS-only applications
  - AutoDesk ADI (protected mode)
  - MicroStation PC (protected mode) Version 4.0
  - MicroStation PC (protected mode) Version 5.0

These drivers provide support for greater speed, higher resolution, and more available colors. The AutoDesk ADI driver also provides additional features when used with the AutoCAD program.

Your DOS, Windows, OS/2, or application software documentation contains explanations of terms and instructions about how to perform common operations. Refer to the documentation, if necessary, as you perform the steps outlined in the remainder of this appendix.

---

## Selecting a Monitor Using the Configuration/Setup Utility Program

Selecting the correct monitor in the Configuration/Setup Utility program allows your system unit to set the monitor to its maximum vertical refresh rate, which provides an image with minimum flicker.

Do the following to access the Configuration/Setup Utility program and to select a video monitor type.

1. Turn on your system unit. If it is on when you start this procedure, you must shut down the operating system, and press Ctrl+Alt+Del to restart the system unit.
2. While the POST memory test is counting, the Configuration/Setup Utility program symbol appears in the upper-right corner of the display screen. Press F1 while the memory is still counting to access the Configuration/Setup Utility program main screen.
3. Select **Devices and I/O Ports**.
4. Select **Video Setup**.
5. Select **Video Display Type**.
6. Select your monitor type from this list.

### Notes:

- a. If your monitor is not shown in the list, select the **Custom** option and select the maximum refresh rate the monitor supports for each resolution. Do not select a refresh rate that is too high for your monitor. Doing so produces an unreadable image and could damage the monitor.
  - b. If a display data channel (DDC) monitor is attached to the system unit, it will be selected automatically in the Configuration/Setup Utility program.
7. Save the settings and restart your system unit.

---

## Installing Windows 3.1 Video Drivers

Use the following for the *initial installation* of Trio64V+ drivers for Windows 3.1. Also, use this procedure to *reinstall* Trio64V+ drivers for Windows 3.1 or to change resolutions for Window 3.1 after the driver has been installed.

To install Windows 3.1 video drivers, do the following.

1. Exit from Windows.
2. Enter **CD\WINDOWS** to change to the WINDOWS directory.
3. Enter **SETUP**.
4. The screen shows the current Windows configuration. Move the highlight bar to the **Display** entry, and press Enter. (*Display* here actually means a monitor mode or video mode provided by a video driver.)
5. You see a list of modes (drivers) from which you can choose. Move the highlight bar to **Other (Requires disk provided by a hardware manufacturer)**, and press Enter.
6. Insert the *S3 Trio64V+ Windows Drivers* diskette in drive A, and press Enter.
7. Select the desired resolution, and press Enter. Refer to the information that comes with your monitor to determine which resolutions your monitor supports.
8. Press Enter to complete the changes.
9. If you get a message that the driver is already installed, press Esc to replace the driver.

10. If you are prompted to insert a diskette, enter **A:\**.
11. When Setup is complete, the DOS prompt appears. Enter **Win** to start Windows. The new video driver is now installed and is controlling your monitor.
12. Repeat this procedure for other resolutions, if desired.

## Alternative Method for Changing Resolutions

You can use the following procedure to change the monitor resolutions.

1. In the Program Manager, select **Main**.
2. In the Main group, select **Windows Setup**.
3. In the Windows Setup window, select **Options**.
4. In the Options menu, select **Change System Settings**.
5. In the Change System Settings window, select **Display**.
6. Select the down arrow at the **Display** field, and select the desired resolution for the S3 Trio64V+ graphics accelerator.

---

## Updating the Windows 3.1 Video Driver

Do the following.

1. Select the VGA driver to control your monitor during the update procedure. This ensures the video driver you are updating is not the same one currently controlling your monitor. Do the following.
  - a. In the Program Manager, select **Main**.
  - b. In the Main group, select **Windows Setup**.
  - c. In the Windows Setup window, select **Options**.
  - d. In the Options menu, select **Change System Settings**.
  - e. In the Change System Settings window, select **Display**.
  - f. Select the down arrow at the **Display** field.
  - g. In the pull-down menu, select the VGA driver, and select **OK**.
  - h. Select **Current** to use the currently installed VGA driver.
  - i. Restart Windows.
  - j. The VGA driver is now controlling your monitor.
2. Delete the existing S3 video driver file to prevent the pull-down menu from becoming filled with multiple versions of the same file. Do the following.
  - a. Open a DOS window.
  - b. In the **WINDOWS\SYSTEMS** subdirectory, find a file named **OEMx.INF**, where *x* is a number. If there is more than one of these files, use a text editor to view the files, and verify which one is the S3 video driver file (near the beginning of the file, you will read "S3 Trio64V+ Windows Drivers Disk").
  - c. Delete the S3 video driver file.
3. Proceed with the installation instructions in "Installing Windows 3.1 Video Drivers" on page F-2.

---

## Installing Windows 95 Video Drivers

Use this procedure for the *initial installation* of Trio64V+ drivers for Windows 95. Also use this procedure to *reinstall* Trio64V+ drivers for Windows 95 and to change resolutions for Windows 95 after the drivers are installed.

To install the Windows 95 drivers, do the following.

1. Start Windows 95.
2. Select **Settings**.
3. Select **Control Panel**.
4. Double click on the **Display** icon. The Display Properties window appears.  
You also can click the right mouse button anywhere on the desktop, and select the Properties option from the pop-up menu.
5. Click on the **Settings** folder.
6. Click on the **Change Display Type...** button. The Change Display Type... window appears.
7. Under Adapter Type, click on the **Change...** button.
8. Click on the **Have Disk...** button.
9. Change directories to A:\ and click on the **OK** button.
10. Select **S3.INF** and click on the **OK** button.
11. Select **S3 Trio64V+ PCI driver** from the list, and click on the **OK** button. If a message stating that one or more driver files are older than the files on the system unit, click on **no**.
12. Click on the **Close** button.
13. Select the appropriate resolution using the Desktop Area and Color Palette options.
14. Click on the **Apply** button. A Systems Settings Change box appears.
15. Click on **Yes** to restart your system unit.

The Windows 95 Trio64V+ driver installation is now complete.

## Alternative Method for Changing Resolutions

To change the resolution after the drivers are installed, do the following.

1. Start Windows 95.
2. Select **Settings**.
3. Select **Control Panel**.
4. Double click on the **Display** icon. The Display Properties window appears.  
You also can click the right mouse button anywhere on the desktop and select the Properties option from the pop-up menu.
5. Click on the **Settings** folder.
6. Select the appropriate resolution using the Desktop Area and Color Palette options.
7. Click on the **Apply** button. A Systems Settings Change box appears.
8. Click on **Yes** to restart your system unit.

---

## Installing Windows NT Video Drivers

Use this procedure for the *initial installation* of Trio64V+ drivers for Windows NT. See step 11 on page F-5 to change resolutions, at a later time, after the drivers have been installed.

1. Start Windows NT.
2. Double-click on the **Control Panel** icon in the Main folder.
3. Double-click on the **Display** icon.
4. Select **Change Display Type...**
5. Select **Change....** on the Display Type screen under the Adapter Type section.
6. Insert the S3 Trio 32/64/64V+ Win NT Display Driver diskette into drive A.
7. Select **S3 Video Driver Update Vx.xx** from the list, and click on **Install**. Click on **Yes** to change the system configuration.
8. If a message appears stating that the driver is already installed, select **New**.
9. Click on **Continue** if prompted for the driver disk a second time.
10. Restart Windows NT when prompted.
11. After Windows NT restarts, select the desired resolution by means of the Display utility program located under the Control Panel in the Main folder. The screen appearance can be changed using the Color Palette, Desktop Area, Refresh Frequency, and Font Size settings.

The Display utility will start automatically the first time the new S3 video driver is loaded.

---

## Installing OS/2 and OS/2 Warp Video Drivers

Use this procedure for the *initial installation* of Trio64V+ drivers for OS/2 and OS/2 Warp and to change resolutions after the driver is installed. To change resolutions after the driver has been installed, start at step 16 on page F-6.

1. Start OS/2, if it is not already running.
2. Double-click on the **OS/2 System** icon.
3. Double-click on the **Command Prompts** icon.
4. Double-click on the **OS/2 Window** icon.
5. Insert the S3 Trio 32/64/64V+ OS/2 Display Driver diskette in drive A.
6. At the command prompt in the OS/2 window, enter **A:**.
7. At the command prompt, enter **SETUP A: C:**.

### Notes:

- a. If OS/2 is not installed on drive C, replace the **C** with the drive letter where OS/2 is installed. For example, if OS/2 is installed on drive D, enter **SETUP A: D:**.
  - b. For the CID (Configuration, Installation, and Distribution) method of installation, use the optional CID parameter. For example, enter **SETUP A: C: CID**.
8. Wait until the Setup program is finished installing the drivers. This can take several minutes. When the Display Driver Install Completed screen is displayed, remove the diskette from drive A.
  9. Restart OS/2 by turning the system unit off and then on, or by pressing Ctrl+Alt+Del.
  10. Run the Display Driver Install program by doing the following.

- a. Double-click on the **OS/2 System** icon.
  - b. Double-click on the **System Setup** folder.
  - c. Double-click on the **Display** icon to start the program.
11. Click on the **Primary Display** icon, and click on **OK**.
  12. Select the S3 Trio 32/64/64V+ driver with the version number that corresponds to the number on the diskette, and click on **OK**. For example, if the version number on the diskette is V2.70-02, select **S3 Trio 32/64/64V+ (32 Bit) Version 2.70-02**.  
**Note:** If a message appears that indicates the target file is newer than the source file, select **yes** to overwrite the target file.
  13. On the Monitor Configuration/Setup Utility screen, select **Install Using Default for Monitor Type**, and click on **OK**.
  14. When the Source Directory screen appears, insert the S3 Trio 32/64/64V+ OS/2 Display Driver diskette into drive A, and click on **Install...**
  15. Wait until the installation is complete; then remove the diskette and restart OS/2 by turning the system unit off and then on, or by pressing Ctrl+Alt+Del.
  16. When OS/2 has restarted, to select the type of monitor, do the following.
    - a. Double-click on the **OS/2 System** icon.
    - b. Double-click on the **System Setup** folder.
    - c. Double-click on the **System** icon.
    - d. Go to the second page of the Screen tab.  
**Note:** If you have a DDC monitor installed, the second page will not be visible, because the DDC monitor is selected automatically.
    - e. Select the type of monitor you have from the list in the Display name pull-down menu.
  17. Go to the first page of the Screen tab and select the desired resolution, color depth, and monitor refresh. You should select the highest refresh rate supported by the monitor, to minimize flicker.
  18. When you are finished selecting the resolution, color depth, and refresh rate, double-click on the upper-left corner of the System Settings window to close it.
  19. Select **Yes** if a screen appears indicating that the system needs to run the SVGA utility program.
  20. Restart OS/2 by shutting down the system unit and pressing Ctrl+Alt+Del. The new resolution, color depth, and refresh rate will be active.
  21. To change the resolution again, perform steps 17 through 20. If you are changing monitors and resolutions, perform steps 16 through 20.

---

## Installing Video Drivers for CAD Panacea

Refer to the instructions for installing the device drivers for CAD Panacea in the ADI1.TXT file on the CAD Panacea Drivers diskette.

---

## Installing Video Drivers for MicroStation PC

Video drivers are provided to support MicroStation PC Version 4.0 and MicroStation PC Version 5.0, both in DOS 386 protected mode. Do the following to install the drivers.

1. Open a DOS window.
2. Insert the DOS Utilities and Microstation Drivers diskette into drive A.
3. Change to drive A by entering **A:**.
4. Enter **CD\MICROSTA** to change to the MicroStation drivers directory.
5. Enter **INSTALL**.
6. Follow the instructions on the screen until the installation is complete.
7. Change to the directory on the hard disk drive where the drivers are installed.
8. Enter **PSCONFIG** to run the PSCONFIG program to select the new device driver.
9. Start MicroStation and do the following to complete the configuration.
  - a. Select **Display Adapters**.
  - b. Select **Vendor Supplied Driver**.
  - c. Select the driver for S3 accelerators.
  - d. Select **No Second Adapter**.
  - e. Select Swap Screen Status **Y** or **N**.
  - f. Select **Exit and Save**.
10. Restart the MicroStation PC program to activate the drivers.

**Note:** The first time you start the MicroStation PC program and activate the drivers, you are asked to select a video resolution. Make sure the resolution you select is supported by your monitor. If you want to use a different resolution at a later time, you must first delete the MGL?S3.CFG file in the USTAT40\DRIVERS directory. The ? in the file name is a version number.





---

# Index

## Numerics

9-pin serial port 4-23

## A

accessing Configuration/Setup Utility program 4-7  
Activity Monitor option 4-20  
adapter slot position 3-7  
adapters, installing 3-2  
adding  
    cache memory 3-8  
    drivers 2-4  
    IBM SBC 3-5  
    internal drive 3-4  
    memory module kits 3-6  
    memory modules 3-6  
    system memory (SIMMs) 3-6  
address conflicts 5-7  
Administrator Password option 4-14  
Advanced Power Management option 4-19  
Advanced Setup option 4-16  
air filters 4-2  
Analog Video PMC Form Factor Card  
    features 7-1  
    removing and replacing 8-37  
APM BIOS Mode option 4-20  
application-specific drivers 4-20  
assignments, serial port 4-23  
Automatic Hardware Power Management option 4-20

## B

backplane and cables (FRUs) 9-2  
backplane, removing and replacing 8-38  
battery failure error message 5-10  
battery, memory-retention 4-22  
baud rate (definition of) 4-23  
BIOS level 8-2  
BIOS, updating 4-28  
blank screen 5-4  
blink codes, POST 8-3  
blink symptoms, LED 8-15  
boot error, hard disk 8-27  
bottom cover (FRUs) 9-5  
broken cover lock 5-5

## C

cable connectors D-3  
cables, connecting 2-2  
cables, disconnecting 8-29

Cache Control option 4-16  
cache memory, installing 3-8  
CAD Panacea video drivers, installing F-6  
card hold-down spacers 3-3  
CGA (color graphics adapter) 4-27  
changing jumpers D-1  
changing logical unit numbers 8-8  
changing or viewing configuration information 4-6, 4-8  
changing resolutions F-3, F-4  
changing selected tests in test groups 8-9  
changing serial port assignments 4-23  
channel assignments, DMA E-2  
check voltage setting 2-1  
checkouts  
    display 8-14  
    general 8-10  
    IBM SBC power-supply connections 8-13  
    keyboard 8-11  
    LED blink symptoms 8-15  
    Module Tests Menu 8-6  
    no-blink symptoms 8-16  
    power supply 8-13  
    printer 8-12  
code page 4-28  
color, high resolution 4-27  
COM1 4-23  
command-line options 8-7  
communications 4-24  
component layout, 7587 Industrial Computer 1-2  
component layout, IBM SBC 6-2  
configuration  
    7587 Industrial Computer 4-1  
    Activity Monitor 4-20  
    administrator password 4-14  
    Advanced Power Management 4-19  
    advanced setup 4-16  
    APM BIOS Mode 4-20  
    Automatic Hardware Power Management 4-20  
    cache control 4-16  
    changing 4-6  
    changing or viewing information 4-8  
    conflicts 4-5  
    CPU Advanced Setup option 4-16  
    date and time 4-12  
    definition 4-4  
    device change 5-13  
    DMA resources 4-19  
    errors 4-5  
    Ethernet Setup option 4-16  
    hardware change 5-9  
    I/O port resources 4-18  
    interrupt resources 4-19

configuration (*continued*)

- ISA legacy resources 4-17
- memory change 5-13
- memory resources 4-18
- overview 4-4
- PCI Control 4-17
- Plug and Play Control 4-17
- power-on password 4-14
- product data 4-8
- purpose 4-6
- ROM shadowing 4-16
- secure hard disk drives and diskette drives 4-13
- start options 4-14
- system security 4-13
- system summary 4-8
- updating system unit 4-6
- utility program 4-6
- video 4-28
- viewing or changing information 4-8

Configuration/Setup Utility program

- accessing 4-7
- Activity Monitor option 4-20
- Administrator Password option 4-14
- Advanced Power Management option 4-19
- Advanced Setup option 4-16
- APM BIOS Mode option 4-20
- Automatic Hardware Power Management option 4-20
- Cache Control option 4-16
- CPU Advanced Setup option 4-16
- Date and Time option 4-12
- description 5-1
- Devices and I/O Ports option 4-9
- DMA Resources option 4-19
- Ethernet Setup option 4-16
- Hard Disk Drive x option 4-12
- I/O Port Resources option 4-18
- IDE Drives Setup option 4-11
- Interrupt Resources option 4-19
- ISA Legacy Resources option 4-17
- main menu screen 4-7
- Memory Resources option 4-18
- moving around the screens 4-7
- options
  - Activity Monitor 4-20
  - Administrator Password 4-14
  - Advanced Power Management 4-19
  - Advanced Setup 4-16
  - APM BIOS Mode 4-20
  - Automatic Hardware Power Management 4-20
  - Cache Control 4-16
  - CPU Advanced Setup 4-16
  - Date and Time 4-12
  - Devices and I/O Ports 4-9
  - DMA Resources 4-19
  - Ethernet Setup 4-16
  - Hard Disk Drive x 4-12

Configuration/Setup Utility program (*continued*)  
options (*continued*)

- I/O Port Resources 4-18
- IDE Drives Setup 4-11
- Interrupt Resources 4-19
- ISA Legacy Resources 4-17
- Memory Resources 4-18
- PCI Control 4-17
- Plug and Play Control 4-17
- Power-on Password 4-14
- Product Data 4-8
- ROM Shadowing 4-16
- Secure Hard Disk Drives and Diskette Drives 4-13
- Start Options 4-14
- System Security 4-13
- System Summary 4-8
- Video Setup 4-10

overview 4-6

- PCI Control option 4-17
- Plug and Play Control option 4-17
- Power-on Password option 4-14
- Product Data option 4-8
- ROM Shadowing option 4-16

run 2-4

- Secure Hard Disk Drives and Diskette Drives option 4-13
- selecting a monitor F-2
- service procedures 8-1
- Start Options option 4-14
- starting 4-7
- System Security option 4-13
- System Summary option 4-8
- using 4-6
- Video Setup option 4-10

conflicts, eliminating assignment 5-7

connecting cables 2-2

connectivity A-2

connector pin-outs 6-7

connectors, cable D-3

connectors, IBM SBC 6-4

cover lock, broken 5-5

cover, remove 3-2

CPU Advanced Setup option 4-16

## D

- data, transferring 4-24
- Date and Time option 4-12
- date and time, setting 4-12
- default resolutions F-1
- detecting POST errors 5-1, 5-2
- device configuration error 5-13
- device drivers
  - installing CAD Panacea F-6
  - installing MicroStation PC F-7

- device drivers (*continued*)
  - installing OS/2 F-5
  - installing Windows 3.1 F-2
  - installing Windows 95 F-4
  - installing Windows NT F-5
  - overview 4-20
- device records B-1
- Devices and I/O Ports option 4-9
- devices, handling discharge-sensitive A-15
- diagnostic
  - command-line options 8-7
  - diskette 5-1
  - error messages 5-2, 5-13
  - errors 5-9
  - programs 5-1
  - QAPlus/PRO program 8-5
  - starting the diagnostic program 8-8
  - tools 5-1, 8-3
- diagnostic tests, extended memory 8-8
- dimensions (7587 Industrial Computer) C-1
- direct memory access (DMA) channel
  - assignments 4-21, 4-22, E-2
- discharge-sensitive devices, handling A-15
- disconnecting cables 8-29
- diskette
  - diagnostic programs 5-3
  - Diagnostics 5-1
  - drive access 4-3
  - drive in-use lights 5-3
  - drive replacement 8-30
  - FRUs 9-3
  - parts catalog 9-3
  - secure drives 4-13
  - starting the diagnostic program 8-8
  - update 4-28
- diskettes drives, secure 4-13
- display
  - blank screen 5-4
  - checkout 8-14
  - distorted screen 5-4
  - error codes 5-2, 5-8
  - jitter 5-4
  - problems 5-4, 5-8
  - rolling screen 5-4
  - selecting 4-27
  - self-tests 5-4
  - support 4-27
  - SVGA 4-26
  - wavy screen 5-4
- DMA channel assignments 4-21, 4-22, E-2
- DMA Resources option 4-19
- driver, installing S3 Trio64V+ Super VGA F-1
- drivers
  - adding 2-4
  - application specific 4-20
  - device specific 4-20

- drivers (*continued*)
  - installing 2-4
  - overview 4-20
  - video 4-26
- drives
  - diskette 4-13
  - diskette drive replacement 8-30
  - hard disk 4-12, 4-13
  - hard disk boot error 8-27
  - hard disk jumper settings D-2
  - in-use lights 5-3
  - installing external device 4-25
  - installing internal 3-4
  - parts catalog 9-3
  - replacing hard disk 8-31
  - secure 4-13

## E

- EEPROM, Flash 4-28
- EGA (enhanced graphics adapter) 4-27
- electrical safety A-11
- electronic emission A-2
- electrostatic devices, handling A-15
- emission, electronic A-2
- enhanced graphics adapter (EGA) 4-27
- environment 1-4
- errors
  - battery failure 5-10
  - code format, POST 8-4
  - configuration 4-5
  - detecting POST 5-2
  - device configuration 5-13
  - diagnostic 5-9, 5-13
  - hard disk boot error 8-27
  - memory configuration 5-13
  - message types 8-4
  - messages 5-2, 5-8, 5-9, 8-21
  - numeric codes 8-17
  - POST 4-6, 5-2, 5-9, 5-10
  - prompt 5-8
  - software 5-9
  - types of messages 8-4
- Ethernet Setup option 4-16
- external serial devices, installing 4-24

## F

- fan (power supply) problems 5-6
- fans and filters (FRUs) 9-6
- feature cards, replacing 8-29
- field-replaceable units (FRUs)
  - backplane and cables 9-2
  - bottom cover 9-5
  - diskette drives 9-3
  - fans and filters 9-6

## field-replaceable units (FRUs) *(continued)*

- hard disk drives 9-3
- IBM SBC 9-5
- keyboards 9-8
- mouse 9-8
- numbers 9-1
- parts catalog 9-1
- power cord 9-9
- top cover 9-4
- Flash (BIOS/VPD) update procedure 8-2
- Flash EEPROM, verifying revision level 4-28
- Flash EEPROMs, updating 4-28
- flicker 4-26
- front fan, replacing 8-32
- front-view dimensions (7587 Industrial Computer) C-1
- FRUs
  - See field-replaceable units (FRUs)

## G

- general checkout 8-10
- general problems 5-5
- general safety A-10
- graphics 4-26
- grounding requirements A-15
- guide, safety inspection A-14

## H

- handling electrostatic-discharge-sensitive devices A-15
- handling static-sensitive devices A-15
- hard disk
  - bad sector 5-8
  - boot error 8-27
  - drive access 4-3
  - drives 4-13
  - FRUs 9-3
  - jumper settings D-2
  - parts catalog 9-3
  - replacing 8-31
  - secure drives 4-13
  - testing 5-8
- hardware
  - diagnostic error messages 5-13
  - problems 5-1, 8-3
  - testing programs 5-1
- heat output 1-4
- high-resolution color 4-27
- hold-down, card spacers 3-3

## I

- I/O Port Resources option 4-18
- IBM SBC
  - See single-board computer (IBM SBC)

- IDE Drives Setup option 4-11
- in-use lights 5-3
- indicator lights problem 5-5
- indicators, IBM SBC 6-3
- industry-standard architecture (ISA)-bus adapters E-1
- input/output ports, configuration information 4-9
- inspection guide, safety A-14
- installing
  - 7587 Industrial Computer 2-1
  - adapters 3-2
  - application programs 4-3
  - cache memory module kits 3-8
  - CAD Panacea video drivers F-6
  - card hold-down spacers 3-3
  - device drivers 2-4
  - external parallel devices 4-25
  - external serial devices 4-24
  - IBM SBC 3-5
  - internal drive 3-4
  - internal options 2-2
  - memory modules 3-6
  - MicroStation PC video drivers F-7
  - operating system 4-2
  - options 3-1
  - OS/2 video drivers F-5
  - parallel devices, external 4-25
  - RAM memory module kits 3-6
  - S3 Trio64V+ Super VGA driver F-1
  - serial devices, external 4-24
  - SIMMs 3-6
  - Windows 3.1 video drivers F-2
  - Windows 95 video drivers F-4
  - Windows NT video drivers F-5
- intermittent problems 5-6
- internal drive, installing 3-4
- interrupt and DMA assignments E-1
- interrupt conflicts 5-7
- interrupt request assignments 4-21, E-1
- Interrupt Resources option 4-19
- ISA Legacy Resources option 4-17
- ISA-bus adapters E-1

## J

- jumpers D-1
- jumpers and switches, IBM SBC 4-22
- jumpers, IBM SBC 6-5

## K

- keyboard checkout 8-11
- keyboard problems 5-6
- keyboardless operation mode 4-4
- keyboards (FURs) 9-8
- kits, installing RAM memory module 3-6

## L

- languages 4-28
- layout, 7587 Industrial Computer components 1-2
- layout, IBM SBC components 6-2
- LED assembly, replacing 8-33
- LED blink symptoms 8-15
- LEDs 4-1
- lights not working 5-5
- lights, in-use 5-3
- lithium battery 4-22
- lock for cover, broken 5-5
- logical unit numbers, changing 8-8

## M

- mass storage device configuration information 4-11
- MCGA (multicolor graphics array) 4-27
- memory configuration error 5-13
- Memory Resources option 4-18
- memory subsystem, IBM SBC 6-3
- Memory Test Group 8-8
- memory-retention battery 4-22
- memory, diagnostic tests 8-8
- memory, installing RAM 3-6
- menu, module tests 8-6
- messages
  - battery failure error 5-10
  - device configuration error 5-13
  - diagnostic error 5-9, 5-13, 8-4
  - Enter password prompt 5-2
  - error 5-2, 8-21
  - memory configuration error 5-13
  - multiple 8-4
  - POST blink codes 8-4
  - POST error 5-1, 5-2, 5-10, 8-4
  - software-generated 8-4
  - types of error 8-4
- MicroStation PC video drivers, installing F-7
- Module Tests Menu 8-6
- module tests selection 8-8
- module tests, running selected 8-9
- monitor, selecting F-2
- mounting 7587 Industrial Computer 2-2
- mouse (FRUs) 9-8
- mouse problems 5-6
- moving around the Configuration/Setup Utility screens 4-7

## N

- no-blink symptoms 8-16
- notices A-1
- numeric error codes 8-17

## O

- occasional problems 5-6
- on/off switch 4-1
- open 7587 Industrial Computer 3-2
- opening the system unit 8-29
- operator information 4-1
- options problems 5-7
- options, adding 3-1
- OS/2 video drivers, installing F-5
- overview of 7587 Industrial Computer 1-1

## P

- parallel devices, external 4-25
- parallel port assignments 4-24
- parallel port mode, changing 4-25
- parts catalog 9-1
- parts warranty 9-1
- passwords
  - administrator 4-14
  - keyboard 4-4
  - power-on 4-3, 4-14, 5-2, 5-6
  - prompt 5-8
  - removing 4-4
  - System Administrator 4-3
- PCI Control option 4-17
- physical dimensions (7587 Industrial Computer) C-1
- pin assignments, serial port D-5
- pin-outs, connector 6-7
- Plug and Play Control option 4-17
- pointing-device problems 5-6
- port assignment conflicts 5-7
- ports, I/O configuration information 4-9
- POST
  - See power-on self-test (POST)
- power cord (FRUs) 9-9
- power supply 1-4, 4-1
- power supply checkout 8-13
- power supply connections for IBM SBC 8-13
- power supply fan problems 5-6
- power supply, replacing 8-31
- power switch 4-1
- power switch, replacing 8-34
- power-on password 5-2, 5-6
- Power-on Password option 4-14
- power-on problems 5-2, 5-7
- power-on self-test (POST)
  - battery failure error 5-10
  - blink codes 8-3
  - description 5-1
  - detecting problems 8-3
  - error 4-6
  - error detection 5-1, 5-2
  - error messages 5-2, 5-10
  - operation 5-1, 5-2

- power-on self-test (POST) *(continued)*
  - problem detecting 8-3
  - updating 4-28
- power, switching off 8-29
- printer checkout 8-12
- printer problems 5-8
- problems
  - diskette drive 5-3
  - display 5-4
  - error prompt 5-8
  - fan 5-6
  - forgotten power-on password 5-6
  - general 5-5
  - hardware 5-1
  - hardware related 8-3
  - intermittent 5-6
  - keyboard 5-6
  - mouse 5-6
  - no LED blinks 5-4
  - occasional 5-6
  - options 5-7
  - overview 5-1
  - password prompt 5-8
  - pointing-device 5-6
  - power-on 5-2, 5-7
  - printer 5-8
  - screen distortion 5-4
  - screen jitter 5-4
  - screen roll 5-4
  - software 5-1, 5-9
  - solving 5-1, 5-2
  - troubleshooting charts 5-3
  - undetermined 8-27
  - user error 5-1
  - wrong number of LED blink 5-4
  - wrong screen characters 5-4
- processor chip, removing and replacing 8-36
- Product Data option 4-8
- program
  - Configuration/Setup Utility 4-6, 5-1
  - diagnostic 5-1, 5-3
  - navigation 8-6
  - power-on self-test (POST) 5-1
  - QAPlus/PRO 8-5
  - system 4-6, 4-28
  - test 8-5
  - utility 4-6

## Q

QAPlus/PRO diagnostic program 8-5

## R

RAM memory module kits, installing 3-6

- records, device B-1
- remove cover 3-2
- removing and replacing
  - Analog Video PMC Form Factor Card 8-37
  - backplane 8-38
  - diskette drive 8-30
  - feature cards 8-29
  - front fan 8-32
  - hard disk drive 8-31
  - IBM SBC 8-34
  - LED assembly 8-33
  - power supply 8-31
  - power switch 8-34
  - procedures for 8-1, 8-28
  - processor chip 8-36
- removing the system unit from its mounting 8-29
- replacement parts 9-1
- requirements, grounding A-15
- resolution 4-26
- resolutions, changing F-3, F-4
- resolutions, default F-1
- restore configuration 4-6
- revision level, verifying Flash EEPROM 4-28
- ROM (read-only memory) 4-28
- ROM Shadowing option 4-16
- running selected module tests 8-9

## S

S3 Trio64V+ Super VGA driver, installing F-1

### safety

- electrical A-11
- general A-10
- information A-10
- inspection guide A-14

### SBC

See single-board computer (IBM SBC)

- scripting 8-8
- Secure Hard Disk Drives and Diskette Drives
  - option 4-13
- security features 4-3
- selected module tests, running 8-9
- selected tests in test groups, changing 8-9
- selecting a monitor F-2
- self-tests, internal 5-1, 5-2
- serial devices, external 4-24
- serial port assignments 4-23
- serial port pin assignments D-5
- service information 8-1
- service parts warranty 9-1
- set date and time 4-12
- SIMMs (single inline memory modules) 3-6
- SIMMs, installing 3-6
- single inline memory modules (SIMMs) 3-6
- single-board computer (IBM SBC)
  - cache memory 3-8

- single-board computer (IBM SBC) *(continued)*
  - component layout 6-2
  - connector pin-outs 6-7
  - connectors 6-4
  - features 6-1
  - FRUs 9-5
  - indicators 6-3
  - installing 3-5
  - jumpers 6-5
  - jumpers and switches 4-22
  - memory subsystem 6-3
  - parts catalog 9-5
  - pin-outs, connector 6-7
  - power-supply connections 8-13
  - remove 3-6
  - removing and replacing 8-34
  - SIMMs 3-6
  - switch functions 6-6
  - switch settings D-4
  - updating Flash EEPROM 4-28
- slot position, adapter 3-7
- software
  - errors 5-9
  - problems 5-1, 5-2
- solving problems 5-1
- spacers, card hold-down 3-3
- special characters 4-28
- specifications 1-3
- Start Options option 4-14
- starting
  - Configuration/Setup Utilityprogram 4-7
  - diagnostic programs 5-3
  - system unit 5-2
- startup-sequence control 4-4
- static-sensitive devices, handling A-15
- stopping tests 8-9
- storage device, mass, configuration information 4-11
- SVGA
  - advantages 4-26
  - controller 4-26
  - description 4-26
  - graphics 4-26
  - languages 4-28
  - software compatibility 4-27
  - special characters 4-28
  - video configuration 4-28
- switch functions, IBM SBC 6-6
- switch, on/off 4-1
- switch, power 4-1
- switch, voltage-selection 5-2
- switches, IBM SBC D-4
- switching off power 8-29
- symptom-to-FRU index 8-14
- symptoms, LED blink 8-15
- symptoms, no-blink 8-16

- system memory (SIMMs) 3-6
- system programs, update 4-28
- system records B-1
- System Security option 4-13
- System Summary option 4-8
- system unit, opening 8-29

## T

- test group, memory 8-8
- test groups, viewing 8-7
- test programs 8-5
- test programs, hardware 5-1
- test programs, using 8-5
- test scripts 8-8
- test the system unit 5-2
- tests menu, module 8-6
- tests, stopping 8-9
- time and date, setting 4-12
- tools, diagnostic 5-1
- top cover (FRUs) 9-4
- top-view dimensions (7587 Industrial Computer) C-2
- trademarks and service marks A-1
- transferring data 4-24
- troubleshooting charts 5-3

## U

- undetermined problems 8-27
- update system programs diskette 4-28
- updating Flash EEPROMs 4-28
- updating system unit configuration 4-6
- user error problems 5-1
- using QAPLus/PRO program 8-5
- using test programs 8-5
- utility program, Configuration/Setup 4-6

## V

- verifying Flash EEPROM revision level 4-28
- vertical-refresh rate 4-27
- video configuration 4-28
- video drivers
  - See device drivers
- Video Setup option 4-10
- video standards 4-27
- viewing serial port assignments 4-23
- viewing test groups 8-7
- vital product data code 8-2
- voltage setting 2-1
- voltage-selection switch 5-2

## W

- warranty service parts 9-1
- Windows video drivers, installing F-2, F-4, F-5





---

# Readers' Comments — We'd Like to Hear from You

**IBM 7587 Industrial Computer**

**Information,  
Installation,  
Operation,  
Hardware Maintenance**

**Publication No. S78H-5454-00**

**Overall, how satisfied are you with the information in this book?**

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Overall satisfaction	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**How satisfied are you that the information in this book is:**

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Accurate	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Complete	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to find	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to understand	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Well organized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Applicable to your tasks	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

**Please tell us how we can improve this book:**

Thank you for your responses. May we contact you? ☐ Yes ☐ No

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you.

\_\_\_\_\_  
Name

\_\_\_\_\_  
Address

\_\_\_\_\_  
Company or Organization

\_\_\_\_\_  
Phone No.




Fold and Tape

Please do not staple

Fold and Tape



NO POSTAGE  
NECESSARY  
IF MAILED IN THE  
UNITED STATES



## BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

International Business Machines Corporation  
WW Production Solutions Information Development  
Department 27X, IMAD 2102  
1798 N.W. SPANISH RIVER BOULEVARD  
BOCA RATON FL 33431-9661



Fold and Tape

Please do not staple

Fold and Tape





Part Number: 76H4589

Printed in U.S.A.

S78H-5454-00



76H4589

